

# Product data sheet

Sheet No.: 1.606.04 - Rev: B  
Date: October 2006

FieldQ

## Actuator assembly codes

### Single acting (Spring Return) assembly codes

|   |           |
|---|-----------|
| <b>Standard assembly code:</b><br>(= Clock Wise Rotation / Spring to Close) | <b>CW</b> |
| <b>Visual indicator mounted:</b><br>(= for In line position indication)     | <b>I</b>  |

|  |           |
|--|-----------|
| <b>Optional assembly code:</b><br>(= Counter Clock Wise Rotation / Spring to Open) | <b>CC</b> |
| <b>Visual indicator mounted:</b><br>(= for In line position indication)            | <b>I</b>  |

|   |           |
|---|-----------|
| <b>Optional assembly code:</b><br>(= Clock Wise Rotation / Spring to Close) | <b>CW</b> |
| <b>Visual indicator mounted:</b><br>(= for Cross line position indication)  | <b>C</b>  |

|  |           |
|--|-----------|
| <b>Optional assembly code:</b><br>(= Counter Clock Wise Rotation / Spring to Open) | <b>CC</b> |
| <b>Visual indicator mounted:</b><br>(= for Cross line position indication)         | <b>C</b>  |

- A = Pilot valve operated in Control Module
- B = Pilot valve not operated in Control Module
- Central air chamber (1) pressurized
- Spring stroke (2)

All views are from above. Pistons are shown in inner position



www.FieldQ.com

Copyright © Emerson Process Management. The information in this document is subject to change without notice. Updated data sheets can be obtained from our web site [www.FieldQ.com](http://www.FieldQ.com) or from your nearest Valve Automation Center: **America's:** +1 813 630 2255 (fax +1 630 9449) **Europe:** +31 74 256 10 10 (fax +31 74 291 09 38) **Asia/Pacific:** +65 626 24 515 (fax +65 626 80 028)



**EMERSON**  
Process Management