

# M-series MD Plus Controller



*The DeltaV MD Plus Controller and the DeltaV I/O subsystem make rapid installation easy.*

- Increases productivity
- Easy to use
- Has the flexibility to meet your needs

## Introduction

The MD Plus Controller provides communication and control between the field devices and the other nodes on the control network. Control strategies and system configurations created on earlier DeltaV systems can be used with this powerful controller. The MD Plus Controller provides all the features and functions of the M5 Plus Controller, with plenty of memory for large batch and other memory-intensive applications.

The control languages executed in the controllers are described in the Configuration Software Suite product data sheet.



## Benefits

### Increases productivity

**Faster.** The MD Plus Controller is more than *400% faster* than the M5 Plus Controller and over 3X the user configurable memory as the MD controller. The Ethernet ports are full duplex, 100MB/second maximum throughput. The results are lower CPU utilization and higher capacity for control strategies.

**Self-addressing.** The DeltaV controller is unique in its ability to automatically identify itself to the DeltaV control network. When the controller is powered up, it is automatically assigned a unique address—no dip switches, no configuring—just *plug and play!*

**Self-locating.** A controller's physical location is easy to find. LEDs on the face of the controller can be made to flash, providing a *strong visual clue*.

**Automatic I/O detection.** The controller can identify all I/O interface channels located on the subsystem. As soon as an I/O interface is plugged in, the controller knows the general characteristics of the field devices managed by that I/O interface. This reduces the no value engineering associated with configuration — *easy!*

### Easy to use

**Total control.** The controller manages all control activities for the I/O interface channels. It also manages all communication functions for the communications network. Time stamping, alarming, and trend objects are also managed within the controller. The controller executes all control strategy with execution speeds up to every 100 ms.

**Data protection.** Each time you install data in a DeltaV controller, the installation information is automatically saved. Likewise, when users make online configuration changes to a controller, the system stores these changes as well. This way, the system always retains a complete record of all the data that has been installed in the controller and any online changes that have been made.

**Cold restart.** This feature ensures that in case of power failure, the controller will restart without manual intervention and without any other device present on the network. Now, you don't have to reboot from the workstation. Simply set the restart state of the controller to current conditions.



The MD Plus Controller

**Note:** To prevent process disruption during a short power loss, an uninterruptible power supply (UPS) is available for the controller.

### Has the flexibility to meet your needs

**Advanced operations.** The MD Plus Controller is equipped to handle the DeltaV Batch option, as well as advanced control functions.

For memory-intensive applications such as Batch, you can create complex control schemes without the risk of running out of memory. This option is recommended for users performing large batch related control where there are many stored phases.

You can also use advanced control function such as Neural and Model Predictive Control on the MD Plus controller.

**Data pass-through.** The controller is equipped with the ability to pass smart HART® information from field devices to any workstation node in the control network. This means you can take advantage of applications, such as Asset Management Solutions, that enable you to remotely manage the HART information contained in your HART or FOUNDATION fieldbus-equipped devices.

**Prepares you for the future.** As your system grows, you can expand your software license to increase the number of device signal tags (DSTs) allocated to the DeltaV controller. Begin with 50 and expand to 750 DSTs. Control strategy complexity and control module scan rates determine overall controller performance and application size. A redundant controller may be added to back up an MD Plus Controller *online*. The standby controller comes online automatically, with a bumpless transition. For more

information, refer to the I/O Redundancy product data sheet.

**Mounting.** This plug-and-play system structure provides modular system growth with a single controller and can be mounted in a Class 1, Div 2 or ATEX Zone II environment.<sup>1</sup> Refer to the System Power Supplies and I/O Subsystem Carriers product data sheets for additional information.

### Designed to support legacy migration

**Advanced operations.** The MD Plus controller provides the DeltaV platform to migrate PROVOX and RS3 controllers, and also supports the PROVOX and RS3 Migration I/O interfaces.

The existing PROVOX I/O remains in place using the migration I/O interface to PROVOX with support of up to 750 real I/O signals. Serial datasets are migrated to DeltaV serial cards and all virtual I/O are no longer required due to the direct module references possible in the DeltaV system.

RS3 system migrations to the DeltaV system are fully supported with MD Plus Controllers and the migration I/O interface for RS3.

---

<sup>1</sup> Refer to Zone 2 installation instructions (12P2046) and/or Class 1 Division 2 installation instructions (12P1293) for details.

Specifications

Power, Mounting, and Memory	
Power requirement	Supplied by System Power Supply through 2-wide Power/Controller Carrier
Fuse protection	3.0 A, non-replaceable fuses
Power dissipation	5.0 W typical, 7.0 W maximum
Mounting	On right slot of power/controller carrier.
User Memory	48 MB
Primary Control Network	8-pin RJ-45 connector
Redundant Control Network	8-pin RJ-45 connector
LED Indicators (ON Status)	
Green – Power	Indicates DC power is applied.
Red – Error	Indicates an error condition.
Green – Active	Indicates that the controller is operating as the primary controller.
Green – Standby	Indicates that the controller is operating as a backup controller (reserved for future use).
Yellow flashing – Pri. CN	Indicates valid primary control network communication.
Yellow, flashing – Sec. CN	Indicates valid secondary control network communication.
All except Power flashing	Visual identification of controller initiated from user interface software by <i>ping</i> command.
All except Power flashing, alternating even and odd	Firmware upgrade in progress.
Environmental	
Operating temperature	-40° to 70° C (-40° to 158° F)
Storage temperature	-40° to 85° C (-40° to 185° F)
Relative humidity	5 to 95%, non-condensing
Airborne contaminants	ISA-S71.04-1985 Airborne Contaminants Class G3 Conformal coating
Shock (normal operating conditions)	10 g ½-sine wave for 11 ms
Hazardous area/location Refer to Zone 2 installation instructions (12P2046) and/or Class 1 Division 2 installation instructions (12P1293) for information on installing in hazardous areas.	ATEX EEx nA IIC T4 Class 1, Div 2, Groups A, B, C, D, T4
Vibration (operative limit)	1 mm peak-to-peak from 5 Hz to 16 Hz, 0.5 g from 16 Hz to 150 Hz

Ordering Information

Description	Model Number
MD-PLUS Controller	VE3006

Prerequisites

- For each controller you will need to select the mounting carrier. Please refer to the I/O Carrier product data sheet for details.
- Each controller requires a dedicated system power supply. Please refer to the Power Supplies product data sheet for details.

To locate a sales office near you, visit our website at:  
[www.EmersonProcess.com/DeltaV](http://www.EmersonProcess.com/DeltaV)  
Or call us at:  
Asia Pacific: 65.777.8211  
Europe, Middle East: 41.41.768.6111  
North America, Latin America: +1 800.833.8314 or  
+1 512.832.3774

For large power, water, and wastewater applications contact Power and Water Solutions at:  
[www.EmersonProcess-powerwater.com](http://www.EmersonProcess-powerwater.com)  
Or call us at:  
Asia Pacific: 65.777.8211  
Europe, Middle East, Africa: 48.22.630.2443  
North America, Latin America: +1 412.963.4000

© Emerson Process Management 2009. All rights reserved. For Emerson Process Management trademarks and service marks, go to:  
<http://www.emersonprocess.com/home/news/resources/marks.pdf>.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available on request. We reserve the right to modify or improve the design or specification of such products at any time without notice.

