



Description

This ELQ electric actuator option provides status information from the ELQ-actuator. Signals are provided for motor running, whether the ELQ-actuator is switched to the Local control box and if the power supply is properly connected. These signals or a combination of these signals can tell what is happening with the ELQ-actuator/valve unit.

Construction

The option consists of an electronic card (1) with three potential free contacts providing the signals and is mounted on top of the mainboard (2). The ELQ-actuator has an intermediate 6 pole connector (3) to connect the status module to the terminals in the terminal compartment.

Specification

Relays : Potential free contacts
Voltage : 0-30V DC/AC
Current : 2 A max.

Signal

Motor running
Switched to Local control
Power present

Status

Contact closed
Contact closed
Contact closed

Identification

Factory Option : Add "+ Q-STM" to the basic actuator size.
: eg. ELQ100 + Q-STM
Kit Option : Actuator size is added to: "Kit, Q-STM"
: eg. Kit, Q-STM/ELQ100